

The North Face® Ridgewall Soft Shell Vest

Size Chart						
	S	M	L	XL	2XL	3XL
Chest	36-38	39-41	42-44	45-48	49-52	53-56

CHEST WIDTH

Measure under the arm and around the fullest part of the chest with arms down, keeping tape horizontal.